

THANK YOU



YUGA
M1

Safety instructions : Sharp blades, risk of cuts.

Keep out of reach of children.

Product intended for domestic and professional use.

Use only YUGA M1-compatible blades.


Before use, ensure that the blade is fully locked in place using the locking knob.

Do not use the product if any part is damaged, loose, or shows abnormal play.

The product contains a permanent magnet. Keep away from implantable medical devices.



OVERVIEW




A: Handle / B: Blade / C: Locking knob / A1: Pins / A2: Magnet


USE

The YUGA M1 blades are attached to and removed from the handle according to the instructions below:


1 UNSCREW



2 POSITION *



3 TIGHTEN



** Orientation: right-handed or left-handed.*

CARE & MAINTENANCE



Hand wash only.

BLADE: Water and soap / Wipe dry.

HANDLE: Wipe clean / Treat with natural wood oil / Avoid prolonged immersion / Do not expose to temperatures above 70°C (risk of demagnetization).



The story continues...

www.yuga-couteau.fr



MADE IN FRANCE